

LECTEURS CD - MP3



GLOBAL-DJ

Code: 15-2210 Carton qty: 2

DUAL CD-MP3/USB/SD CARD PLAYER WITH SCRATCH

- Blue-lit LCD
- 2x CD channels, USB, SD card reader & 1x LINE channel
- Fully programmable with Repeat function
- Triple function JOG dial: Pitch Bend/Scratch/Search
- SCRATCH & DSP (brake & reverse) effect modes
- Pitch control
- Seamless LOOP on every player with RELOOP function
- Instant start & CUE with preview



Power supply :100-240Vac, 50/60Hz
Dimensions : 503 x 442 x 155mm

ISCRATCH101-V2

Code: 15-2222 Carton qty: 4

TOP LOAD CD/MP3 PLAYER WITH DSP AND SAMPLER

Full MP3 functions with 1 line text display.

- Slot-in mechanism
- ID3 Tag Display with Neon Blue LED Display
- Relay play
- 9 DSP effects with direct access including reverse
- USB Audio output for Mix Vibes Control's DVS Le Software
- FX : Scratch, Filter, Echo, Trans, Skid, Phase, Flanger, Pan, Reverse.
- Direct access of X & Y Parameter in REAL TIME
- Giant Sensitive Jog Wheel for Scratch, Search and Pitch.
- Customizable Jog's Settings
- 4 Sampler bank and 4 HOT CUE.
- Saves up to 3,000 cue points in memory transferable to compatible units
- SSM mode: Sampler Scratch Mode
- ± 6 , 12, 25 and 100% pitch control on CD's and MP3's.
- $\pm 100\%$ Key Lock with key control on CD's and MP3's
- Seamless LOOP with Reloop
- 48 seconds of Anti-Shock buffer memory
- User-updateable operating system
- Direct Folder Access with Quick Track +10
- High Glossy Black Panel for Controller and Main unit.
- Supplied incl. **DJ Mix Vibes software**



Order on-line at www.lotronic.com